



## BENTON CITY WATER SUPPLY CORP.

P.O. BOX 1210  
21180 NAEGELIN ROAD  
LYTLE, TEXAS 78052  
(830)709-3254

### NEW MEMBER CONNECTION INFORMATION

Please read the following before connecting to our service:

- Do not use black rolled Poly pipe
- Suggested pipe sizes from meter to house:
  - Up to 150 feet - 1 inch to 1 ¼ inch
  - 150 to 300 feet - 1 ¼ inch to 1 ½ inch
  - More than 300 feet - 1 ½ inch to 2 inch
- Flush the pipe to your house for several minutes before connecting to the house
- Have several faucets open when you first turn the meter on
- Turn all faucets off and check for leaks. *(Toilets and small faucet drips can use lots of water and cause high water bills!!)*
- Check small “Star” leak indicator in center of the meter to see if water is leaking. *(If the “Star” spins, water is running somewhere. Check all pipes and fittings.)*
- Let all faucets run a few minutes and flush toilets to see how they handle the pressure
- Check the “Star” leak indicator each couple of hours to see if leaks have begun

**You will be responsible for all water that passes through the meter.**

**Leak prevention will save you money!**